



DESPIECE PR0520 - PR0630


序号 NO.	图号 Part NO.	英文名称 Part Name	数量 Qty.
A	BG63.5	Gear Case Ass'y	
1	GB893.2	Stop Ring 28	1
2	GB894.1	Stop Ring 12	1
3	GB/T276	Bearing 6001-2RS/P5	1
4	GB/T276	Bearing 6001/P5	2
5	BG63.5-2	Pinion	1
6	GB70.1+GB93+GB97	Screw M6×35	1
7	GB70.1+GB93	Screw M5×14	1
8	GB70.1	Screw M5×8	4
9	GB70.1	Screw M6×8	1
10	BG63.5-1	Gear Case	1
11	GB/T276	Bearing 6000/P5	1
12	BG63.5-3	Gear	1
13	BG63.5-4	Gear Shaft	1
14	GB/T276	Bearing 6202-2RS/P5	1
15	GB893.2	Stop Ring 35	1
16	BG63.5.1	Oil-seal	1
17	BG63.5-8	Holder A	1
18	BG63.5-5	Washer	1
19	BG63.5-6	Holder B	1
20	BG63.5-7	Cover	1
21	BG63.5-9	Nut	1




B			
1	3GC520-9	Grip Left	1
2	CG330-E-GGP-5	Handle	1
3	3GC520-1	Cap, Upper	1
4	BC36. 4-2+GB93+GB97	Screw M6×50	1
5	BC36. 4-2+GB93+GB97	Screw M5×30	2
6	3GC520-2	Cap, Lower	1




C			
1	3GC520. 1	Clutch Comp.	
2	CG63. 3. 1	Clutch Drum Comp	1
3	GB893. 1 φ 35	Stop Ring 35	1
4	GB276 6202-2RS/P5	Bearing 6202-2RS/P5	1
5	GB894. 1 φ 15	Stop Ring 15	1
6	3GC520-8	Rubber column	2
7	GB70. 1+GB93+GB848	Screw M6×20	4
8	3GC520. 1-1	Clutch Case	1
9	CG63. 3-2	Rubber	1
10	CG63. 3-4	Washer	1
11	GB893. 1 φ 48	Stop Ring 48	1
12	CG63. 3-3	Linker	1
13	GB70. 1+GB93+GB97. 1	Screw M6×30	1
14	GB70. 1	Screw M5×12	1




D			
1	BG63.4.1	Drive Bearing	6
2	CG63.1-2	Drive Shaft	1
3	CG63.1-1C	Pipe	1




E	3GC520.2	Lever Ass 'y	
1	3GC520.2-4	Button	1
2	3GC520.2.1	Box, Left	1
3	3GC520.2-3	Handgrip	1
4	CG330-E-GGP.2-1	Rubber, Seal	1
5	CG260A-E-GGP.1-5	Clamp	2
6	CG330-E-GGP.2-4	Rubber Ring	2
7	GB70.1	Screw M5×12	2
8	3GC520.2-5	Spring	1
9	3GC520.2-2	Handgrip	1
10	3GC520.2-6	Spring	1
11	3GC520.2-1	Box, Right	1
12	GB845 ST3.5×16	Screw ST3.5×16	4
13	CG330-E-GGP.2-2	Rubber Ring	1
14	3GC520.2.2	Stop Button Comp.	1
15	BG-328A-2	Tube	1
16	3GC520.2.3	Cable Comp.	1




H	BG63. 10	Nylon Cutter Head	
1	BG63. 10. 1	Case	1
2	BG63. 10-1	Spring	1
3	BG63. 10. 3	Cord Holder	1
4		Cord $\phi 2.5 \times 5000$	1
5	BG63. 10. 2-2	Cord Cover	2
6	BG63. 10. 2	Cover	1



I	CG520-HL-2	Blade Ass'y	1
J	BC46. 3	Harness	1
K	CG520-HL-2	Blade Cover	1





1E48F-EP GASOLINE ENGINE

NO.	PART NO.	PART NAME	QTY.	NO.	PART NO.	PART NAME	QTY.	NO.	PART NO.	PART NAME	QTY.
1	1E48F-EP.1-1	Cleaner Outside Cover	1	25	GB6170	NUT M8	2	49	1E48F-EP.5.1-2	Fly Wheel	1
2	1E48F-EP.1-2	Filter Net	1	26	GB6172	NUT M8	2	50	GB/T97	Washer 10	1
3	GB70.1-GB93	Screw MSX55	2	27	GB70.1-GB93+GB97	Screw MSX12	1	51	GB/T93	Washer 10	1
4	1E48F.1-3	Baffle	1	28	1E48F-E-7	Gasket	2	52	GB/T6171	Nut M10X1	1
5	1E48F-EP.1.1	Cleaner inside cover	1	29	1E48F-E-1	Gasket	1	53	1E48F-EP.2	Starter	1
6	1E40F-2E.1B-GGP	Carburetor	1	30	1E48FP.5-3	Piston Ring	1	54	GB70.1-GB93+GB97	Screw MSX20	6
7	1E48FP-6	Gasket	1	31	1E48FP.5-4	Piston Ring	1	55	1E48F-EP.5.1-3	Coil	1
8	GB70.1-GB93+GB97	Screw MSX30	2	32	1E48FP-E.1-1	PISTON	1	56	1E36F-2C.6.1	Cord Comp.	1
9	1E48FP-5	Admitting Pipe	1	33	P40.6-4	RING	2	57	1E48F-EP.5.1-1	Cap	1
10	1E48F-5	Gasket	1	34	1E48FP.5-2	PISTON PIN	1	58	1E36F-2C.6-2	Spring	1
11	1E48F-E-2	cylinder	1	35	1E44F-2A.2-3	Bearing	1	59	L8RTC	Plug	1
12	1E48F-EP-3	Clapboard	1	36	1E48F.7.1	Crank Shaft Ass'y	1	60	1E48F-EP.4	Fuel Tank	1
13	GB70.1-GB96	Screw MSX12	1	37	GB1099	KEY 3X5X13	1	61	1E53F.2	Rubber Pillar	3
14	1E48F-EP.3	Guide Cover Ass'y	1	38	1E48FP.6-2	Gasket	1	62	1E48F-EP-2	Stand	1
15	GB/T70.1	SCREW MSX16	1	39	GB/T276	Bearing 6202/P6	2	63	GB/T96	Washer 5	3
16	1E33F-4	Gasket	3	40	GB119	Pin 4h8X10	2	64	GB/T6177	NUT M5	3
17	GB70.1-GB93+GB97	Screw MSX16	2	41	1E48F.8-1	Crank Case	1	65			
18	1E48F-EP-1	Muffler Cover	1	42	1E40FP-3Z-11	Seal	2	66			
19	GB/T70.1	SCREW MSX20	4	43	1E48F-E.5	Clutch	1	67			
20	1E40F-5-13E	BOLT	2	44	1E40F-6-14	Washer 6	1	68			
21	1E48F-EP-5	Gasket	1	45	GB/T93	Washer 6	1	69			
22	1E48F-EP-4	Gasket	1	46	1E40F-6-4	Bolt	1	70			
23	1E48F-E.2GGJ	Muffler	1	47	1E48F.8-2	Crank Case	1	71			
24	1E48F-E-3GGJ	Muffler Cover	1	48	GB70.1	Screw MSX30	4	72			
								73			