



Ref. No.	Description (Chinese)	Description (English)
1	大梁	beam
2	M10*25内六角沉头螺钉	M10*25 hexagon screw
3	大梁护板(上左板)	beam protect table(lefttop)
4	M10螺母	M10 nut
5	大梁护板(右板)	beam protect table(righttop)
6	大梁护手	embrace frame(right:left)
7	大梁护手盖	embrace frame rubber cap
8	大梁护板(上右板)	beam protect table(right top)
9	四通阀安装板	control valve fitting
10	M8*35内六角螺钉	M8*35 hexagon screw
11	螺母	nut
12	双手操作手柄	control handle
13	四通阀进油管	inlet hose(pump hose)
14	3/4英寸接头	3/4 to 1/2 connector
15	刀头挂块	blade fitting (Set 2 pcs)
16	M10*45十字沉头螺钉	M10*45 cross screw
17	1/2英寸接头	1/2 connector
18	油箱上油管	ram hose(top)
19	油箱下油管	ram hose(bottom)
20	油箱	tank
21	四通阀	control valve
22	大梁手柄	beam handle
23	M8*100内六角沉头螺钉	M8*100 hexagon screw
24	油缸进油口	ram pin
25	开口销3.2*50	3.2*50 cotter pin
26	橡胶密封圈	seal ring set
27	长杆定位套	fitting of beam and towbar
28	M12*30内六角螺钉	M12*30 hexagon screw
29	链条	chain
30	M12*85外六角螺栓	M12*85 hex bolts
31	链条	chain
32	M10*70外六角螺栓	M10*70 hex bolts
33	挡泥板	mud fender
34	油泵	suction hose
35	轮胎	wheel
36	内螺纹软管接头	thread hose connector
37	外螺纹软管接头	external thread hose connector
38	M12防松螺母	M12 locknut
39	螺母	nut
40	M20开口螺母	M20 opening nut
41	轮胎轴盖	wheel hub cap
42	刀片	blade
43	油箱	tank
44	挡泥板	mud fender
45	长杆	towbar
46	油箱口密封圈	tank cap rect seal
47	油箱口盖钩	tank cap fitting
48	油箱盖密封圈	tank cap seal ring
49	油箱盖衬圈	tank cap filler
50	O形圈	O ring
51	油箱盖	tank cap
52	汽油机联轴器	engine coupler
53	油泵联轴器	pump coupler
54	汽油机	engine
55	联轴器连接块	connector frame
56	联轴器盖	coupler cap
57	油泵	pump
58	长杆轴销	pin of towbar and beam
59	M8*20外六角螺栓	M8*20 hex bolt
60	大梁护板(下板)	beam protect table(leftbottom)
61	大梁护板(右板)	beam protect table(righttop)
62	M8*16十字沉头螺钉	M8*16 cross bolt
63	9#88轴销	9#88 pin
64	橡胶轴销	O pin
65	四通阀回油管	return hose
66	M8防松螺母	M8 locknut
67	轴销	axlesher
68	轴销垫片	O10washer
69	轴销垫片	O12washer
70	轴销螺母	wheel screw nut